







ASSEMBLY INSTRUCTIONS

PARTS LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	13	1	M5 Size Allen Wrench
2	1	Base	8	1	Backrest Post	14	1	M6 Size Allen Wrench
3	1	Seat Post	9	1	Backrest Post Screw	15	1	Air Pump
4	1	Seat Post Cover (Optional)	10	6	Mechanism Screw	16	1	Air Pump Holder (optional)
5	1	Mechanism	11	1	Backr Tight Bolt	TORQUE SETTINGS TO FIX ALL BOLTS: 1.6Nm		
6	1	Seat	12	1	Backrest Bellow			



ATTENTION

1. THIS ASSEMBLY INSTRUCTION IS ONLY FOR ASSEMBLING THE CHAIR. THE CHAIR DRAWING MAY BE DIFFERENT FROM CHAIR APPEARANCE.
2. SOME SCREWS MAY PREASSEMBLED , ASSEMBLERS CAN IGNORE THE STEP.
3. REMOVE ALL ITEMS FROM THE CARTON. VERIFY ALL PIECES BEFORE ASSEMBLY.

PREVENTIVE MAINTENANCE AND WARNING!

- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
- DISPOSE OF PACKAGING PROPERLY.
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.