



Assembly Instructions

MODEL NO: CSC2FD




Pin 6x35 1 25PCS	Cam 2 25PCS	Lock 11 1PCS
Cam Cover 3 25PCS	Shelf Pin 4 12PCS	Wood Screw 4x20 12 4PCS
Hinge(Inset) 5 8PCS	T-Handle 6 2PCS	73x23x15 13 2PCS
Handle Screw 4x22 7 4PCS	Wood Screw 4x18 8 50PCS	ø6x40 14 2PCS
Wood Screw 3.5x13 9 18PCS	ADJ. Feet ø42x25H 10 4PCS	Wood Screw 4x40 15 2PCS


STEP1



STEP2




STEP3



First insert the pin(part#1), then place the cam(part#2), and finally tighten/lock off after they have been put into the melamine.

IMPORTANT NOTE:


- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO:CSC2FD


STEP4







STEP5



STEP6




STEP7



IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children




Assembly Instructions

MODEL NO: CSC2FD


The warning sticker provided within this hardware kit **MUST** be attached to the piece furniture in a place that is 100% visible when the item is empty.

STEP8

Make a mark with a pencil




STEP9




Drill holes at the marks with an electric drill

STEP10




STEP11


WALL



STEP12



⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This furniture type is at high risk of toppling over

Ask staff for more information or visit <https://www.productsafety.gov.au>

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children

